


Installation instruction

ULTRA Granite measuring plates

The right setting for measuring plates, which are stored on individual supports, tool cabinets or steel stands etc. is absolutely necessary to assure a consistent and repeatable accuracy.



The correct, tension-free installation works as follows:

1. Placing the plate on the three predefined bearing points (see picture - **black dots**)
2. Level on these three bearing points (x and y axis) by adjusting the spindles using a spirit level.
3. Tighten all other adjustment screws of the support elements by hand only. (anti-tilt protection – see picture - **white dots**)



● *Aufstell- und Nivellierungspunkte*